

Daily Startup and Shutdown Procedure

Follow the simple checklist below as you start up each day before blasting and as you shut down at the end of the day:

| Startup Before Blasting | Shut Down After Blasting |
|---|---|
| 1. Ensure all equipment is setup with Whipchecks that are fitted correctly <input type="checkbox"/> | 1. Depressurise the pot (a) Shut the choke valve <input type="checkbox"/> |
| 2. Start compressor <input type="checkbox"/> | (b) Release deadman handle <input type="checkbox"/> |
| 3. Close choke valve <input type="checkbox"/> | 2. Empty moisture separator <input type="checkbox"/> |
| 4. Ensure deadman handle is working <input type="checkbox"/> | 3. Turn off compressor/air supply <input type="checkbox"/> |
| 5. Check pressure. <input type="checkbox"/> | 4. Replace lid on blast pot (to prevent rain/condensation getting into the abrasive). <input type="checkbox"/> |

Save time, extra maintenance and possible breakdowns!