



BLASTECH

MASTERFIELD
INDUSTRIAL EQUIPMENT

Spray Ultra High Build coatings easier

Ultimately, the best solution for spraying Ultra High Build coatings is a plural component sprayer.

Should, however, UHB coating have to be sprayed with standard single-leg machines, the following 12 tips will help ensure a successful job:

- 1.** Select the right size pump
- 2.** Gravity feed material
- 3.** Use the correct size filter
- 4.** Pump coating within the correct temperature range
- 5.** Use correct size airless hose
- 6.** Use the correct gun
- 7.** Use the correct size tip
- 8.** Heat coating with extreme care
- 9.** Use a high 'cut' solvent
- 10.** Clean the entire system thoroughly at the end of your shift
- 11.** Clean hopper of previous batch of material before filling with new batch
- 12.** Flush pump throughout shift



Call Blast-One today for advice on your next UHB project!

Ph **1800 882 229**

Email sales.au@blast-one.com

Web www.blast-one.com.au