

Good Pressure – Good Production!

Step 1

Place hypodermic needle onto nipple at the base of the gauge.



Step 2

Insert the needle into the blast hose slowly, a few inches back from the nozzle.

Point the needle toward the nozzle, and at a slight angle. Insert slowly until you get a constant reading.

Are you getting 100psi?



Step 3

Record reading and remove needle.
Pack away for next time.



Testing your pressure allows you to identify and rectify your pressure loss problems